



LRV 主要尺寸表

口径		主要尺寸 (mm)																				概算重量 (kg)
mm	inch	d	D	C	D ₁	C ₁	d ₂	L	H ₂	H ₁	l	T	t	b	t ₁	N	K	N ₂	S	N ₃	B	
1000	40	951	1175	1120	300	254	70	280	713	693	75	50	30	22	9	24	30	4	M27	8	18	665
1100	44	1076	1300	1240	300	254	75	280	775	751	78	50	30	25	10	24	30	4	M27	8	18	761
1200	48	1176	1405	1340	300	254	80	280	828	801	89	50	30	25	10	28	33	4	M30	8	18	845
1300	52	1274	1525	1450	350	298	85	280	893	861	95	55	40	28	12	28	36	4	M33	8	22	1035
1400	56	1374	1630	1560	350	298	90	280	945	913	107	55	40	28	12	32	36	4	M33	8	22	1150
1500	60	1480	1730	1660	350	298	95	280	993	978	120	55	40	28	12	32	36	4	M33	8	22	1240
1600	64	1568	1830	1760	415	356	100	280	1050	1027	132	60	40	28	12	36	36	4	M33	8	33	1460
1800	72	1774	2045	1970	415	356	115	280	1157	1142	136	60	40	32	13	40	39	4	M36	8	33	1825
2000	80	1974	2265	2180	415	356	125	280	1267	1257	157	60	40	32	12	44	42	4	M39	8	33	2263

